READ ME FIRST

Basic Cable Connections - HP rp2400 Series of Servers - Document Changes

The document *Basic Cable Connections - HP rp2400 Series of Servers* has been revised. See the table below.

IMPORTANT The latest versions of these documents, and any updates to these documents, are posted under the appropriate server at http://docs.hp.com.

Ver. 1.0 Page #	Ver. 2.0 Page #	Description of Change
2	2	Send documentation comments to http://docs.hp.com/assistance/index.html.
3	7	For detailed installation, maintenance, and technical information, refer to the *rp24xx Hardware Manual* and other documentation (search on *rp2400*) at http://docs.hp.com.
4	8	2. *(Amber) Attention (ATTN) LED* - When lit, indicates that a condition exists that requires operator attention and assistance from HP Support. **NOTE:** For technical support please call your local support hotline or contact HP at http://www.hp.com/support.
5	9	**NOTE:** For more information on console configuration, refer to the *rp24xx Hardware Manual* (search on *rp2400*) at http://docs.hp.com. **Using a Secure Web Console PCI card as a System Console**. If the Secure Web Console PCI card is to be used as a system console, first configure the Guardian Service Processor (GSP). For more information on GSP configuration, refer to the *rp24xx Hardware Manual* (search on *rp2400*) at http://docs.hp.com. Then, connect an RJ45 LAN cable to the Secure Web Console PCI card installed in an I/O card slot on the back of the server.
6	10	**Using the LAN Console as a System Console**. If a LAN Console is to be used as a system console, first configure the Guardian Service Processor (GSP). For more information on GSP configuration, refer to the *rp24xx Hardware Manual* (search on *rp2400*) at http://docs.hp.com. Then, connect it to the system with an RJ45 LAN cable to the RJ45 connector labeled *10BASE-T LAN Console* connection on the back of the server.
6	10	**NOTE:** [regarding connecting Power Distribution Units (PDUs) to Dedicated AC Input Receptacles] Current requirements vary with input voltage, server configuration, and number of power supplies installed. Refer to "System Site Preparation" in the *rp24xx Hardware Manual* at http://docs.hp.com.

Downloaded from www.Manualslib.com manuals search engine